



## **OEM NFPA 1901/1906 Foam Single-Point Injection Proportioner Test Procedure**

### **2000 / 3000 Series Foam Systems**

- 1) Foam pump and water flowmeters must be calibrated per Installation and Operation Manual before testing (Concentrate viscosity must be within the foam proportioner manufactures limits)
- 2) Tools needed for the test are a pitot tube or other calibrated flowmeter to test the system water flow rates. A graduated bucket to collect and calibrate foam concentrate. A stop watch to measure volume unit/time of foam concentrate flow. A load valve to control system back pressure capable of maximum flow of the foam system pump. Appropriate pressure gauge to measure back pressure.

On larger systems, it may be practical to use a calibrated flowmeter instead of a graduated collection container and recirculate the foam concentrate.

- 3) System performance is dependent on flowmeter/pipe size. Identify applicable OEM test points based on size of flowmeter installed. Maximum water flow is determined by the flowmeter range or the maximum water pump output, whichever is less.
- 4) Water and foam concentrate can be tested separately on FoamPro 2000 and 3000 series systems as follows:
  - A) Test main waterway flowmeter at the three (3) test points shown on applicable OEM Certification test chart (If the water pump cannot reach the maximum flowmeter rate at 150psi use maximum flow rate of the pump). Water flow rates displayed on the control head should be within 10% of pitot tube measurements.
  - B) Test the foam pump at three (3) test points shown on OEM Certification test chart.
    - 1) Turn the "Cal/Inject" valve to the Calibrate position (Foam system should be primed with no air in the lines).
    - 2) Attach pressure gauge and load valve to the "cal/inject" valve with a hose running to graduated bucket.
    - 3) Enter "Simulated Flow" mode and set the water flow rate to the value listed in the chart for the flowmeter size.
    - 4) Set the percent (%) concentrate to the corresponding value specified in the chart.
    - 5) Press the "ON" button to start the proportioner.
    - 6) Set the load valve back pressure to the corresponding value specified in the chart.
    - 7) Run the system for short period (Not less than 5 seconds electric driven, 20 seconds hydraulic) to assure prime and stabilization. Note the volume of concentrate in the bucket and start the stop watch.
    - 8) Run the system for several minutes. Note the volume in the bucket and time on the stop watch. (Note: Longer run time will increase measurement accuracy)
    - 9) Divide the volume change in the bucket (total concentrate pumped during the timed period) by the number of minutes on the stop watch. The result must match the corresponding Foam (GPM) listed in the chart within NFPA accuracy requirements. (Note: NFPA allows -0% to +40% for solutions of less than 1% and -0% to +30% for solutions greater than 1%; or 1 percentage point whichever is less)
    - 10) Repeat this process for remaining two (2) rows of the OEM Certification Test chart. All three scenarios must meet NFPA guidelines without re-calibrating.
- 5) If system has multiple concentrate tanks, repeat step B for each additional tank.



NFPA 1901 / 1906  
Model 2001 Foam System Certification



A Safe Fleet Brand

System Certified

OEM Certification Test

**1 1/2" Thread or 2" Victaulic W/1" Bore**

Range	Water Flow	Range	Back Press. PSI	Foam %	Range	Foam Cap. (gpm)
Min	5	Min	0	0.2%	Min	0.01
Max	110	Max	125	2.4%	Max	2.60
Min	5	Max	400	0.2%	Min	0.01
Max	110	Min	0	2.7%	Max	3.00
Mid	55	Mid	125	4.7%	Mid	2.60

Flowmeter		Foam Pump Test Points					
Range	Test Points	Sim Water Flow	Set Foam %	Range	Back Press. PSI	Range	Foam (gpm)
Mid	40	100	0.8%	Mid	400	Mid	0.80
Min	5	5	0.2%	Min	0	Min	0.01
Max	110	100	2.6%	Max	125	Max	2.60

**1 1/2" Thread or 2" Victaulic**

Range	Water Flow	Range	Back Press. PSI	Foam %	Range	Foam Cap. (gpm)
Min	10	Min	0	0.1%	Min	0.01
Max	320	Max	125	0.8%	Max	2.60
Min	10	Max	400	0.1%	Min	0.01
Max	320	Min	0	0.9%	Max	3.00
Mid	155	Mid	125	1.7%	Mid	2.60

Flowmeter		Foam Pump Test Points					
Range	Test Points	Sim Water Flow	Set Foam %	Range	Back Press. PSI	Range	Foam (gpm)
Mid	90	100	0.8%	Mid	400	Mid	0.80
Min	10	10	0.1%	Min	0	Min	0.01
Max	320	100	2.6%	Max	125	Max	2.60

**2" Thread or 2 1/2" Victaulic**

Range	Water Flow	Range	Back Press. PSI	Foam %	Range	Foam Cap. (gpm)
Min	15	Min	0	0.1%	Min	0.01
Max	520	Max	125	0.5%	Max	2.60
Min	15	Max	400	0.1%	Min	0.01
Max	520	Min	0	0.6%	Max	3.00
Mid	260	Mid	125	1.0%	Mid	2.60

Flowmeter		Foam Pump Test Points					
Range	Test Points	Sim Water Flow	Set Foam %	Range	Back Press. PSI	Range	Foam (gpm)
Mid	160	100	0.8%	Mid	400	Mid	0.80
Min	15	10	0.1%	Min	0	Min	0.01
Max	520	100	2.6%	Max	125	Max	2.60

**2 1/2" Thread or 3" Victaulic**

Range	Water Flow	Range	Back Press. PSI	Foam %	Range	Foam Cap. (gpm)
Min	20	Min	0	0.1%	Min	0.02
Max	750	Max	125	0.3%	Max	2.60
Min	20	Max	400	0.1%	Min	0.02
Max	750	Min	0	0.4%	Max	3.00
Mid	385	Mid	125	0.7%	Mid	2.60

Flowmeter		Foam Pump Test Points					
Range	Test Points	Sim Water Flow	Set Foam %	Range	Back Press. PSI	Range	Foam (gpm)
Mid	250	100	0.8%	Mid	400	Mid	0.80
Min	20	20	0.1%	Min	0	Min	0.02
Max	750	100	2.6%	Max	125	Max	2.60

**3" Thread or 4" Victaulic**

Range	Water Flow	Range	Back Press. PSI	Foam %	Range	Foam Cap. (gpm)
Min	30	Min	0	0.1%	Min	0.03
Max	1150	Max	125	0.2%	Max	2.60
Min	30	Max	400	0.1%	Min	0.03
Max	1150	Min	0	0.3%	Max	3.00
Mid	590	Mid	125	0.4%	Mid	2.60

Flowmeter		Foam Pump Test Points					
Range	Test Points	Sim Water Flow	Set Foam %	Range	Back Press. PSI	Range	Foam (gpm)
Mid	375	100	0.8%	Mid	400	Mid	0.80
Min	30	30	0.1%	Min	0	Min	0.03
Max	780	100	2.6%	Max	125	Max	2.60

**4" Thread or 5" Victaulic**

Range	Water Flow	Range	Back Press. PSI	Foam %	Range	Foam Cap. (gpm)
Min	55	Min	0	0.1%	Min	0.06
Max	1980	Max	125	0.1%	Max	2.60
Min	55	Max	400	0.1%	Min	0.06
Max	1980	Min	0	0.2%	Max	3.00
Mid	1020	Mid	125	0.3%	Mid	2.60

Flowmeter		Foam Pump Test Points					
Range	Test Points	Sim Water Flow	Set Foam %	Range	Back Press. PSI	Range	Foam (gpm)
Mid	625	100	0.8%	Mid	400	Mid	0.80
Min	55	55	0.1%	Min	0	Min	0.06
Max	1980	100	2.6%	Max	125	Max	2.60

Type tested to all known Class A and B Foam Concentrates including Alcohol Resistant Concentrates up to 2000 cps